

Toll Restriction for Hotel Room Phones

The following programming will allow a front desk instrument to change call restrictions for a guest room phone. Codes 1, 2, and 3 are used in the programming example below. Care should be taken when assigning to an existing site as these codes may already be utilized for other Hotel features. Access codes 1 through 8 are available for this application.

The programming shown will reflect the following operations.

1. From the Front desk instrument, allow unrestricted dialing from a guest room phone.
 - Depress the STS key.
 - Dial 1.
 - Depress the STS key again.
 - Dial the guest room number.
 - Depress the SET key. The above two steps can be repeated for other stations.
 - Depress the RLS key.

2. From the Front Desk Instrument, restrict calls to internal, local, 0+ (Credit Card Calls), and toll free only for a guest room phone.
 - Depress the STS key
 - Dial 2
 - Depress the STS key again.
 - Dial the guest room number.
 - Depress the SET key. The above two steps can be repeated for other stations.
 - Depress the RLS key.

3. From the Front Desk Instrument, restrict calls to internal only for a guest room phone.
 - Depress the STS key.
 - Dial 3.
 - Depress the STS key again.
 - Dial the guest room number.
 - Depress the SET key. The above two steps can be repeated for other stations.
 - Depress the RLS key.

4. From the Front Desk Instrument, check the status of a particular guest room phone.
 - Depress the STS key.
 - Dial the guest room number.
 - Depress the SET key.
 - Display shows the current status 1, 2, or 3.
 - Depress the RLS key.

Programming Procedure

1. D031>101>1
2. D031>201>1
3. D031>300>1
4. D031>208>1
5. 08>232>1
6. D015>Guest Rm>0 (Default setting)
7. D016>0006>1
8. D016>0046>1
9. D026>Rte 00-63>0 (Default setting)
10. D027>0000>0083
11. D027>0001>0013
12. D027>0002>9
13. D027>0003>9
14. D027>0004>9
15. D027>0005>9
16. D027>0006>9
17. D027>0007>9
18. D027>0008>9
19. D027>0009>9
20. D027>0010>9
21. D027>0011>9
22. D027>0012>9
23. D027>0013>9
24. D027>0014>9
25. D027>0015>9
26. D027>0016>9
27. D027>0017>9
28. D027>0018>0023
29. D027>0019>9
30. D027>0020>0033
31. D027>0021>9
32. D027>0022>9
33. D027>0023>9
34. D027>0024>9
35. D027>0025>9
36. D027>0026>0043
37. D027>0027>0053
38. D027>0028>0063
39. D027>0029>9
40. D027>0030>9
41. D027>0031>9
42. D027>0032>9
43. D027>0033>9
44. D027>0034>9
45. D027>0035>9
46. D027>0036>9
47. D027>0037>9
48. D027>0038>9
49. D027>0039>9
50. D027>0040>9
51. D027>0041>9
52. D027>0042>9
53. D027>0043>9
54. D027>0044>9
55. D027>0045>9
56. D027>0046>9
57. D027>0047>9
58. D027>0048>9
59. D027>0049>9
60. D027>0050>9
61. D027>0051>9
62. D027>0052>9
63. D027>0053>9
64. D027>0054>9
65. D027>0055>9
66. D027>0056>9
67. D027>0057>9
68. D027>0058>9
69. D027>0059>9
70. D027>0060>9
71. D027>0061>9
72. D027>0062>9
73. D027>0063>9
74. D027>0064>9
75. D027>0065>9
76. D027>0066>9
77. D028>0067>9
78. D027>0068>9
79. D027>0069>9
80. D027>0080>9
81. D027>0081>9
82. D027>0082>9
83. D027>0083>9
84. D027>0084>9
85. D027>0085>9
86. D027>0086>9

87. D027>0087>9
 88. D027>0088>9
 89. D027>0089>9
 90. D033> Rte 00-63>0 (Default setting)
 91. D034>0000>0080
 92. D034>0001>0010
 93. D034>0002>11
 94. D034>0003>11
 95. D034>0004>11
 96. D034>0005>11
 97. D034>0006>11
 98. D034>0007>11
 99. D034>0008>11
 100. D034>0009>11
 101. D034>0010>21
 102. D034>0011>21
 103. D034>0012>21
 104. D034>0013>21
 105. D034>0014>21
 106. D034>0015>21
 107. D034>0016>21
 108. D034>0017>21
 109. D034>0018>0020
 110. D034>0019>21
 111. D034>0020>0030
 112. D034>0021>21
 113. D034>0022>21
 114. D034>0023>21
 115. D034>0024>21
 116. D034>0025>21
 117. D034>0026>0040
 118. D034>0027>0050
 119. D034>0028>0060
 120. D034>0029>21
 121. D034>0030>11
 122. D034>0031>21
 123. D034>0032>21
 124. D034>0033>21
 125. D034>0034>21
 126. D034>0035>21
 127. D034>0036>21
 128. D034>0037>21
 129. D034>0038>21
 130. D034>0039>21
 131. D034>0040>21
 132. D034>0041>21
 133. D034>0042>21
 134. D034>0043>21
 135. D034>0044>21
 136. D034>0045>21
 137. D034>0046>11
 138. D034>0047>21
 139. D034>0048>21
 140. D034>0049>21
 141. D034>0050>21
 142. D034>0051>21
 143. D034>0052>21
 144. D034>0053>21
 145. D034>0054>21
 146. D034>0055>21
 147. D034>0056>21
 148. D034>0057>11
 149. D034>0058>21
 150. D034>0059>21
 151. D034>0060>21
 152. D034>0061>21
 153. D034>0062>21
 154. D034>0063>21
 155. D034>0064>21
 156. D034>0065>21
 157. D034>0066>21
 158. D034>0067>21
 159. D034>0068>11
 160. D034>0069>21
 161. D034>0080>21
 162. D034>0081>21
 163. D034>0082>11
 164. D034>0083>11
 165. D034>0084>11
 166. D034>0085>11
 167. D034>0086>11
 168. D034>0087>11
 169. D034>0088>11
 170. D034>0089>11
 171. 9000>XXXX,01>F1069 (STS key and
where XXXX= the Front Desk
Instrument)
 172. 9000>XXXX,02>F1074 (SET key)
 173. 9000>XXXX,03>F1077 (RLS key)
- Note:** If you still require an SMDR output for allowed local calls in Status 2 set all assignments in CMD027 that =1 to a 9.