Call Park Orbit Keys

I used to install a lot of Nitsuko Onyx systems and really liked the "Park Orbit" feature where 3 or 4 park locations appeared on the station sets. A real key system feature but great for small installs.

So If you have 1900R2 or higher you can accomplish this with the "Remote Hold" feature. Here's generally how it works.

- 1. Attendant (Dterm) receives a call presses one of the one touch "Park Orbit" keys followed by "Hold".
- 2. The called is placed on hold and the "Park Orbit" on the attendant Dterm will light solid while the associated "Park Orbit" key on the Dterm sets will flash red.
- 3. The Attendant access the paging system to announce the call. E.g. "There is a call on Park 1 for Bob Smith"
- 4. Bob Smith goes to any Dterm set and accesses the flashing "Park 1" key and converses with the calling party.
- 5. If Bob Smith fails to pick up the call it recalls to the attendant set with "Park 1" showing in the display.

Programming Procedure

- 1. CM 10>700~103>F2500~F2503 Where 700~703 = a Non-equiped LEN and F2500~F2503 are the "Park Orbit" stations that match the numbering plan. Create one station for each Park Orbit you wish to utilize.
- 2. CM 9000>X-XXXXXXXX,01~24>2500~2503 Where X-XXXXXXXX = Each Dterm set you wish to use the "Park Orbit" keys on. In most cases this will be all of them. 2500~2503 are the Phantom Dterm stations created back in step 1. Make sure that if you create 4 Phantoms you place the 4 Phantoms on each set. There is no need to place these on the actual Attendant set.
- 3. CM 9001>X-XXXXXXXX,01~24>0 Where X-XXXXXXX= the stations addressed in step 2. Remove the ringing from the Dterm keys that display the "Park Orbit" stations.
- 4. CM 171>X-XXXXXXXX>2 Assign Off Hook Suppress to each of the "Park Orbit" stations assigned in step 1.
- 5. CM 15124>00~15>0 Allow the Remote Hold feature for the Service Restriction Class A of the Attendant station.
- 6. CM 771>X-XXXXXXXXPARK1 Assign a user-friendly name to each "Park Orbit" station. Keep the characters to 8 or less to get the name to display on the recall.
- 7. CM 410>06>XX Adjust the recall timer to recall the parked call to the Attendant position after the desired time.
- 8. At the Attendant set program one touch keys with the "Park Orbit" stations. You can also assign these to keys on a DSS console.